

Installation Guide

1 System Requirements

XP/Windows7/Windows 8.1/Windows10/Windows11

2 Hardware Required


- Host: A computer with a 1GHz or faster 32-bit (x86) or 64-bit (x64) processor.
- Memory: 1GB RAM (32-bit) operating system or 2GB RAM (64-bit) operating system.
- Hard disk space: more than 200MB.
- Display: 800×600 resolution.

3 Software Installation Procedure


1. Link website <https://www.tenmars.com/>
or scan below QR code:




2. Search TM-184A.
3. Click on the TM-184A photo.
4. Click **File Download**, then select **Software** Download.
5. Download and unzip the software.
6. Run autorun.exe, and click to install the following software.



7. Connect this product to a computer with included USB cable.



8. To execute desktop program: double click the program icon to start it.



9. See Software Installation Guide for details on software [User Manual](#).