

1. Remove nut on power socket



2. Remove 6 screws from back of enclosure



3. Remove front of enclosure, pull top part away first then slide power connector out.



4. Remove battery and replace with new



5. Reassembly unit by doing these steps in reverse.

