

MODEL NO.:ST-9211A/B/C

Waterproof T-Bar Robust Digital Thermometer

FUNCTION:

- A** ON/OFF, H/T FUNCTION
- B** ON/OFF, °F/°C FUNCTION
- C** ON/OFF, MAX/MIN (°F/°C) MEMORY RECALLING FUNCTION



FEATURES:

- ONE HOUR AUTO SHUT OFF
- 133MM. ROBUST STAINLESS STEEL SENSOR PROBE
- MAX/MIN (°F/°C) MEMORY RECALLING
- TEMPERATURE UNIT °F/°C SELECTABLE
- DATA HOLD/TEST FUNCTION SELECTABLE
- 1 SEC. NORMAL TEMPERATURE SENSING TIME
- PROTECTIVE PLASTIC SLEEVE WITH CLIP FOR STAINLESS STEEL
- LOW BATTERY INDICATOR

SPECIFICATION:

- MEASUREMENT RANGE: []-50°C ~ +150°C OR -58°F ~+302°F
[]-50°C ~ +300°C OR -58°F ~+572°F
- RESOLUTION:0.1° FOR -19.9° ~ +199.9°, OTHERWISE 1°
- ACCURACY : []±1°C IN THE RANGE OF -30°C ~ +150°C
[]±1.8°F IN THE RANGE OF -22°F ~ +302°F
[]±1°C IN THE RANGE OF 151°C ~ +250°C, OTHERWISE MORE THAN ± 2°C
[]±1.8°F IN THE RANGE OF 303.8°F ~+482°F, OTHERWISE MORE THAN ± 4°F
- AMBIENT TEMPERATURE FOR PLASTIC CASING: -10°C ~ +50°C OR +14°F ~ +122°F
- BATTERY : 1 X 1.5V "A76" SIZE (LR 44, G13 OR EQUIVALENT)

OPERATION:

PRESS THE "ON/OFF" BUTTON TO SWITCH ON THE THERMOMETER.

- "°F/°C" BUTTON -- TO SELECT DESIRED TEMPERATURE UNIT.
- "H/T" BUTTON -- TO RETAIN READING FOR RECORDING. THE WORD "HOLD" WILL FLASH ON THE DISPLAY.
- "MAX / MIN" BUTTON -- THE "MIN" SIGN WILL BE SHOWN. THE MINIMUM TEMPERATURE TESTED WILL DISPLAY. PRESS THE BUTTON AGAIN. THE "MAX" SIGN WILL BE SHOWN. THE MAXIMUM TEMPERATURE TESTED WILL DISPLAY. IT WILL GO BACK TO THE TESTING POSITION AUTOMATICALLY AFTER THREE SECONDS.

PRECAUTIONS:

- TO OBTAIN THE BEST RESULTS, THE PROBE TIP SHOULD BE IMMERSSED AT LEAST 10MM. INTO THE TESTED SUBSTANCE.
- REMOVE THE BATTERY FROM THE BATTERY COMPARTMENT IF THE THERMOMETER WILL NOT BE USED FOR LONG DURATION OF TIME OR DURING STORAGE.
- THE THERMOMETER CANNOT BE USED OR PUT INSIDE ANY OVEN OR MICROWAVE.