

# DIGITAL CLOCK HYGRO-THERMOMETER

## SPECIFICATION

- ◆ Measuring Temperature Range:  $-50^{\circ}\text{C} \sim 70^{\circ}\text{C}$  ( $-58^{\circ}\text{F} \sim +158^{\circ}\text{F}$ )
- ◆ Temperature Accuracy:  $\pm 1^{\circ}\text{C}$  ( $\pm 2^{\circ}\text{F}$ )
- ◆ Temperature Display Resolution:  $0.1^{\circ}\text{C}$  ( $0.2^{\circ}\text{F}$ )
- ◆ Measuring Humidity Range: 10%RH ~ 99%RH
- ◆ Humidity Accuracy:  $\pm 5\%$
- ◆ Humidity Display Resolution: 1%RH
- ◆ Max/Min Temperature and Humidity Memory Records
- ◆ Operating Voltage: 1.5v, one AAA batter
- ◆ Indoor/outdoor temperature
- ◆ Indoor Relative Humidity & clock function
- ◆ Sampling Period: 6S
- ◆ Total Dimension: 110mm x 100mm x 20mm
- ◆ LCD Dimension: 80mm x 60mm
- ◆ Net Weight: Approx. 145g

## FEATURE

- ◆ Large LCD screen shows time indoor/outdoor temperature, and humidity.
- ◆ Stand for shelf or hanging hole at back side.
- ◆ Max/Min temperature and humidity memory records
- ◆ ROHS and CE certification

## BUTTONS & OPERATIONS

- ◆ **MODE SET** Button:  
Press for short time to select clock mode and alarm mode.  
Press for long time to set the clock time, setting order is min-hour-confirm.
- ◆ **ADJ** Button: Under setting mode, press it to adjust the setting object.  
When not under setting mode:  
Press it to select 12/24 hour system under the time mode.  
Press it to select the alarm on/off under alarm clock mode.
- ◆ **MIN/MAX** Button  
-Press **MIN/MAX** key to display the maximum temperature and maximum indoor humidity.  
-Press **MIN/MAX** key again to display the minimum temperature and minimum indoor humidity.  
-At the state of MIN or MAX, press and hold MIN/MAX button for 2 seconds to clear MAX and MIN temperature, humidity.
- ◆  **$^{\circ}\text{C} / ^{\circ}\text{F}$**  Button (at the back)  
Selectable  $^{\circ}\text{C} / ^{\circ}\text{F}$  display by  **$^{\circ}\text{C} / ^{\circ}\text{F}$**  Button.